

Code: USB/RS485

## CONVERTER **USB/RS485**

The USB/RS485 converter allows to the PC computer the devices controlled via RS-485 interface.

ATTENTION! On hardwares with many COM ports, it may be necessary to check the assigned COM port number. You can do it by: Device Manager -> Ports (COM and LPT). You can change the assigned COM port number using Device Manager - Advanced Options for a port.



|                      |  |
|----------------------|--|
| Input:               | USB  |
| Number of inputs:    | 1 pcs  |
| Output:              | RS-485   |
| Number of outputs:   | 1 pcs  |
| Communication:       | <ul style="list-style-type: none"> <li>• fluent bidirectional transmission (half duplex)</li> <li>• one-directional continuous transmission</li> </ul> |
| Connectors:          | USB<br>Cable terminals   |
| Transmission range:  | 1200 m (9600 b/s)  |
| Baud rates:          | max. 115 kbps  |
| System requirements: | Windows XP/Vista/7/8/10, Linux   |
| Power connector:     | USB  |
| Power supply:        | from USB port  |
| Guarantee:           | 2 years  |